

Easy Go

New



- Use as a one step machine for skipping, finger print, light scratches or multi stage for deep scratches and gauges.
- Removes light, medium and heavy scratches
- Light weight, silent motor, safe compounds make the CD or DVD look brand new every time.

- No water ! You do not have to deal with filter, water pump, water hose, or dirty water !
- Information given on the exchange of
- Easy to operate.
- Voltage: 110 V and 220 V
- Size: H 29 x W 24 x D16 cm
- Weight: 2 kg